

FIG. D COMMON DEDICATED CIRCUITS

Appliance	Power Required (watts)
Electric Range	10,000 (240 volts)
Electric Dryer	5,000 (240 volts)
Space Heater	1,000 and up
Clothes Washer	1,150
Furnace (blower)	800
Microwave	700–1,400
Refrigerator (not required)	700
Freezer (not required)	700
Dishwasher	1,400
Central Vacuum	800
Whirlpool/Jacuzzi	1,000 and up
Garbage Disposer	600–1,200
Kitchen Countertop (two circuits)	
<i>Toaster</i>	900
<i>Coffee maker</i>	800
<i>Toaster oven</i>	1,400
Bathroom	
<i>Blow dryer</i>	1,000–2,000