

## Materials List

ITEM	QTY.	ITEM	QTY.
3/8" x 4' x 8' rough-sawn exterior plywood	3	1-5/8" exterior screws	1 lb.
1/2" x 4' x 8' BC grade plywood	1	2-1/2" galv. finish nails	1 lb.
1x2 x 8' pine	1	1-1/2" galv. finish nails	1 lb.
1x2 x 8' cedar	3	1" narrow crown staples (for cedar shingles)	1 lb.
1x3 x 8' pine	2	30-lb. felt	1 roll
1x3 x 8' cedar	2	10" x 10' roll aluminum flashing	1 roll
1x4 x 8' cedar	7	2-1/2" x 2-1/2" rust-resistant hinges	3 prs.
Cedar shakes	1 bundle	Magnetic catches	1 pr.
2x4 x 8' cedar	11	Handles	1 pr.
4x4 x 4' pressure treated	1		
2-1/2" exterior screws	2 lbs.		

---

Note: We used rough-sawn cedar boards—which usually (but not always!) measure 7/8 in. thick—for the trim. If you substitute pine, which measures 3/4 in., subtract 1/8 in. from each door width.